



VAPEBERRI User Manual



Made in China

EN Welcome to VAPEBERRI and thank you for purchasing our product. You must be 18 years or older to purchase or use this product.

Notice for Customer:

Thank you for choosing VAPEBERRI products! Please read this manual carefully before use so as to use correctly. If you require additional information or have questions about the product or its use, please consult your local agents or contact us directly.

Product Introduction:

VAPEBERRI temperature control box mod is an outstanding product implementing the latest technology that combines a luxury appearance and miniature size. You can set the temperature of atomizer in advance to protect the atomizer and device. It is artful and easy to enjoy. There are two colors for your choice: black and red Variable wattage from 5.0w to 40.0w. The Joule is adjustable from 2.5J to 20J

1

Parameter:

- Variable Wattage: 5.0w-40.0w
- Variable Joule: 2.5J-20.0J
- Normal atomizer resistance: 0.2Ω-3.0Ω
- Pure nickel 200 or TI coil atomizer resistance : 0.1Ω-1.0Ω
- Temperature control : 200°F - 600°F and 100°C - 300°C
- Size: 34mmX24mmX65mm
- Color: black,red
- Internal Battery : 1500mah 18500 (20A)
- Connection: Stainless Steel Spring Loaded 510 Connection

2

How to Use:

1. Five clicks fire button in 2 seconds to turn ON the Device, OLED screen show "HELLO". Then displaying: battery condition, resistance X.XXΩ, voltage X.XXV, and Joule XX.XJ, Ni or Ti, temperature X.XX°F(°C) in Joule Mode, or Wattage: X.XXW, Current: X.XA in Power Mode . Five clicks to turn OFF the device.

40.0W $\frac{0.000}{0.00V}$ $\frac{0.0A}{0.0A}$

2. Adjust the wattage/Joule: Press the +/- button to increase or decrease the wattage/Joule by 0.1w/0.1J each time. The wattage is adjustable vary from 5.0W to 40.0W. And the Joule is adjustable vary from 2.5J to 20J. The voltage is adjustable automatically. Without any operation in 2 seconds, the screen light will be weak. Without any operation in 10 seconds, the screen will be closed and then go into sleep state, press any button will back to normal state.

3

- When keep pressing the fire button for over 10 seconds one time, the output will shut off. The screen show "OVER TIME".
- In Joule Mode: Press the fire button and + button in the same time for 3 seconds, the screen will show the power, press the +/- button to adjust it. Press the fire button to exit the adjustment.
- In Joule Mode, when without E-liquid in the atomizer, the OLED screen show "NO LIQUID".
- Protection Function : Reverse connection protection, short circuit protection, low voltage protection and high temperature protection.
- Press the + and - button at the same time, it will set the atomizer resistance.
- Press the fire button and - button at the same time, it will lock the power, when it is locked, you can vape but can't adjust the device.

4

Three clicks of fire button in 2 seconds to functions menu:

MENU		FUNCTION
JOULE MODE	NI-TC	UNIT °F (200°F - 600°F), UNIT °C (100°C - 300°C) to adjust the temperature
	TI-TC	
POWER MODE		EXIT to wattage adjustment state
SYSTEM	SCREEN	RIGHT / LEFT / NORMAL / STEALTH
	SENSI	Adjust the sensitivity from 1 to 20
	COURT	XXXXT(puffs) XXXXS(total time) CLR COURT(clear court)
EXIT		back to normal state

5

How to charge:

Connect USB cable to charge directly.

Precautions:

Only have your VAPEBERRI repaired by VAPEBERRI. Do not attempt to repair the unit yourself as damage or personal injury may occur. Do not leave the VAPEBERRI in high temperatures or damp conditions because it may be damaged. The appropriate operation temperature is 0°C to 45°C while charging and -10°C to 60°C while using.

6

Warranty:

Please consult your VAPEBERRI product warranty card. We are not responsible for any damages caused by human error. Our warranty is not available for products purchased from third-party vendors.

7